

Extracted Python Code

Below is the complete Python code extracted from your Jupyter Notebook.

```
!pip install ultralytics
```

```
# =====  
# New Cell  
# =====
```

```
import os  
import cv2  
import numpy as np  
import matplotlib.pyplot as plt  
from ultralytics import YOLO  
from tqdm import tqdm  
import csv  
from datetime import timedelta
```

```
# -----  
# Config / user-editable params  
# -----  
VIDEO_PATH = "/content/drive/MyDrive/input_video.mp4"    # <-- path to your  
top-view video  
OUTPUT_VIDEO = "output_annotated.mp4" # <-- annotated output video  
CSV_OUTPUT = "vehicle_counts.csv"    # counts per frame/time  
SAMPLE_EVERY_N_FRAMES = 1          # process every frame, set >1 to skip frames to  
speed up  
MODEL_WEIGHTS = "yolov8n.pt"        # pre-trained weights. Change to yolov8m.pt /  
yolov8l.pt if desired  
DEVICE = "cuda"                     # 'cuda' or 'cpu' ; use 'cuda' if you have GPU  
CONF_THRESH = 0.35                  # detection confidence threshold (tunable)  
IOU_THRESH = 0.45                   # nms iou threshold (model config handles it usually)  
MIN_BOX_AREA = 200                   # ignore tiny boxes (in pixels) - tunable for top view  
# Density thresholds (tunable to your scene)  
DENSITY_THRESHOLDS = {  
    "low": 5,  
    "medium": 15, # <= medium threshold considered medium; > medium => high  
}  
  
# Classes of interest (COCO default class names indices):  
# COCO names:
```

<https://github.com/ultralytics/ultralytics/blob/main/ultralytics/yolo/data/coco.yaml>

We'll map to vehicle classes.

VEHICLE_CLASS_NAMES = ["car", "motorcycle", "bus", "truck", "bicycle"] #

optionally include 'person' if needed

=====

New Cell

=====

Helper functions

def classify_density(total_count, thresholds=DENSITY_THRESHOLDS):

if total_count <= thresholds["low"]:

return "LOW"

elif total_count <= thresholds["medium"]:

return "MEDIUM"

else:

return "HIGH"

def draw_overlay(frame, bbox, cls_name, conf, color=(0,255,0)):

bbox = [x1,y1,x2,y2]

x1, y1, x2, y2 = [int(v) for v in bbox]

cv2.rectangle(frame, (x1,y1), (x2,y2), color, 2)

label = f'{cls_name} {conf:.2f}'

(w, h), _ = cv2.getTextSize(label, cv2.FONT_HERSHEY_SIMPLEX, 0.5, 1)

cv2.rectangle(frame, (x1, y1 - 18), (x1 + w, y1), color, -1)

cv2.putText(frame, label, (x1, y1 - 3), cv2.FONT_HERSHEY_SIMPLEX, 0.5,
(255,255,255), 1, cv2.LINE_AA)

Load model

print("Loading YOLO model:", MODEL_WEIGHTS)

model = YOLO(MODEL_WEIGHTS) # automatically loads weights

Set model config (confidence threshold) - we will filter results manually too

model.conf = CONF_THRESH # (alternative to manual filtering)

Prepare video I/O

cap = cv2.VideoCapture(VIDEO_PATH)

if not cap.isOpened():

raise FileNotFoundError(f"Cannot open video file {VIDEO_PATH}")

```

fps = cap.get(cv2.CAP_PROP_FPS) or 25.0
width = int(cap.get(cv2.CAP_PROP_FRAME_WIDTH))
height = int(cap.get(cv2.CAP_PROP_FRAME_HEIGHT))
total_frames = int(cap.get(cv2.CAP_PROP_FRAME_COUNT))

fourcc = cv2.VideoWriter_fourcc(*'mp4v')
out_vid = cv2.VideoWriter(OUTPUT_VIDEO, fourcc, fps /
SAMPLE_EVERY_N_FRAMES, (width, height))

print(f"Video opened: {VIDEO_PATH} (frames={total_frames}, fps={fps},
size={width}x{height})")

# Load COCO names if possible (Ultralytics may have built-in names)
COCO_NAMES = model.names if hasattr(model, 'names') else None
if COCO_NAMES is None:
    COCO_NAMES = {0: 'person'} # fallback; but ultralytics usually provides names

# Map desired vehicle class indices
vehicle_class_ids = [i for i, n in COCO_NAMES.items() if n in
VEHICLE_CLASS_NAMES]

# Prepare CSV
csv_file = open(CSV_OUTPUT, mode='w', newline='')
csv_writer = csv.writer(csv_file)
csv_writer.writerow(["frame_idx", "time_s", "car_count", "motorcycle_count",
"bus_count", "truck_count", "bicycle_count", "total_count", "density"])

# Process frames
frame_idx = 0
processed = 0
counts_over_time = []

pbar = tqdm(total=total_frames // SAMPLE_EVERY_N_FRAMES + 1,
desc="Processing frames")
while True:
    ret, frame = cap.read()
    if not ret:
        break
    frame_idx += 1
    if (frame_idx - 1) % SAMPLE_EVERY_N_FRAMES != 0:
        continue

# Inference
# Note: ultralytics model can accept numpy BGR images directly

```

```

results = model.predict(source=frame, conf=CONF_THRESH, device=DEVICE,
imgsz=640, verbose=False)

# results is a list; take the first
res = results[0]
boxes = getattr(res, 'boxes', None)
car_count = motorcycle_count = bus_count = truck_count = bicycle_count = 0

# Draw detections
if boxes is not None and len(boxes) > 0:
    # boxes.boxes: xyxy, boxes.cls, boxes.conf in new versions. Use attributes robustly.
    # Get arrays safely
    xyxy = boxes.xyxy.cpu().numpy() if hasattr(boxes, 'xyxy') else np.array([])
    cls_ids = boxes.cls.cpu().numpy().astype(int) if hasattr(boxes, 'cls') else np.array([])
    confidences = boxes.conf.cpu().numpy() if hasattr(boxes, 'conf') else np.array([])

    for i, (b, cls_id, conf) in enumerate(zip(xyxy, cls_ids, confidences)):
        x1, y1, x2, y2 = b
        area = (x2 - x1) * (y2 - y1)
        if area < MIN_BOX_AREA: # ignore tiny boxes
            continue
        cls_name = COCO_NAMES.get(int(cls_id), str(cls_id))
        # Count vehicle classes
        if cls_name == 'car':
            car_count += 1
        elif cls_name == 'motorcycle':
            motorcycle_count += 1
        elif cls_name == 'bus':
            bus_count += 1
        elif cls_name == 'truck':
            truck_count += 1
        elif cls_name == 'bicycle':
            bicycle_count += 1
        # draw
        draw_overlay(frame, b, cls_name, float(conf))

    total_count = car_count + motorcycle_count + bus_count + truck_count +
bicycle_count
    density_label = classify_density(total_count)

# Overlay counts and density on frame
info_text = f'Frame: {frame_idx} Vehicles: {total_count} Density: {density_label}'
cv2.putText(frame, info_text, (10, 25), cv2.FONT_HERSHEY_SIMPLEX, 0.7, (0,0,0),
4, cv2.LINE_AA)
cv2.putText(frame, info_text, (10, 25), cv2.FONT_HERSHEY_SIMPLEX, 0.7,

```

```
(255,255,255), 1, cv2.LINE_AA)
```

```
# Add colored density band
if density_label == "LOW":
    band_color = (0, 255, 0)
elif density_label == "MEDIUM":
    band_color = (0, 215, 255)
else:
    band_color = (0, 0, 255)
cv2.rectangle(frame, (0, height-40), (width, height), band_color, -1)
cv2.putText(frame, f"Density: {density_label}", (10, height-12),
cv2.FONT_HERSHEY_SIMPLEX, 0.7, (255,255,255), 1, cv2.LINE_AA)

# Write frame to output video
out_vid.write(frame)

# Record counts
time_s = frame_idx / fps
csv_writer.writerow([frame_idx, f"{time_s:.3f}", car_count, motorcycle_count,
bus_count, truck_count, bicycle_count, total_count, density_label])
counts_over_time.append((frame_idx, time_s, total_count, density_label))

processed += 1
pbar.update(1)

pbar.close()
csv_file.close()
cap.release()
out_vid.release()
print(f"Processing complete. Processed frames: {processed}")
print(f"Annotated video saved to: {OUTPUT_VIDEO}")
print(f"Counts CSV saved to: {CSV_OUTPUT}")

# =====
# New Cell
# =====

# -----
# Plot: Vehicle count vs time
# -----
frames = [x[0] for x in counts_over_time]
times = [x[1] for x in counts_over_time]
totals = [x[2] for x in counts_over_time]
densities = [x[3] for x in counts_over_time]
```

```

plt.figure(figsize=(12,5))
plt.plot(times, totals, marker='o', linewidth=1, markersize=3)
plt.title("Vehicle count vs Time")
plt.xlabel("Time (s)")
plt.ylabel("Vehicle count (per frame)")
# Highlight density thresholds
low_thr = DENSITY_THRESHOLDS["low"]
med_thr = DENSITY_THRESHOLDS["medium"]
plt.axhline(low_thr, linestyle='--', label=f"Low threshold ({low_thr})")
plt.axhline(med_thr, linestyle='--', label=f"Medium threshold ({med_thr})")
plt.legend()
plt.grid(True)
plt.tight_layout()
plt.savefig("vehicle_count_timeseries.png", dpi=200)
print("Plot saved to vehicle_count_timeseries.png")
plt.show()

```

```

# =====
# New Cell
# =====

```

!pip install ultralytics opencv-python-headless matplotlib tqdm

```

# =====
# New Cell
# =====

```

```

VIDEO_PATH = "/content/drive/MyDrive/input_video.mp4"    # Your input video
OUTPUT_VIDEO = "output_annotated.mp4" # Annotated video will be saved here
MODEL_WEIGHTS = "yolov8n.pt"      # Use small YOLO model for speed

```

```

# =====
# New Cell
# =====

```

"""

Traffic Density Estimation using YOLOv8 (Ultralytics)

Requirements:

- Python 3.8+
- pip install ultralytics opencv-python-headless matplotlib numpy tqdm

If you have a GPU, make sure ultralytics sees it (CUDA installed) and set device='cuda' in

```

config.
"""

import os
import cv2
import numpy as np
import matplotlib.pyplot as plt
from ultralytics import YOLO
from tqdm import tqdm
import csv
from datetime import timedelta

# Density thresholds (tunable to your scene)
DENSITY_THRESHOLDS = {
    "low": 5,
    "medium": 15, # <= medium threshold considered medium; > medium => high
}

# Classes of interest (COCO default class names indices):
# COCO names:
https://github.com/ultralytics/ultralytics/blob/main/ultralytics/yolo/data/coco.yaml
# We'll map to vehicle classes.
VEHICLE_CLASS_NAMES = ["car", "motorcycle", "bus", "truck", "bicycle"] #
optionally include 'person' if needed

# -----
# Helper functions
# -----
def classify_density(total_count, thresholds=DENSITY_THRESHOLDS):
    if total_count <= thresholds["low"]:
        return "LOW"
    elif total_count <= thresholds["medium"]:
        return "MEDIUM"
    else:
        return "HIGH"

def draw_overlay(frame, bbox, cls_name, conf, color=(0,255,0)):
    # bbox = [x1,y1,x2,y2]
    x1, y1, x2, y2 = [int(v) for v in bbox]
    cv2.rectangle(frame, (x1,y1), (x2,y2), color, 2)
    label = f"{cls_name} {conf:.2f}"
    (w, h), _ = cv2.getTextSize(label, cv2.FONT_HERSHEY_SIMPLEX, 0.5, 1)
    cv2.rectangle(frame, (x1, y1 - 18), (x1 + w, y1), color, -1)
    cv2.putText(frame, label, (x1, y1 - 3), cv2.FONT_HERSHEY_SIMPLEX, 0.5,

```

```

(255,255,255), 1, cv2.LINE_AA)

# -----
# Load model
# -----
print("Loading YOLO model:", MODEL_WEIGHTS)
model = YOLO(MODEL_WEIGHTS) # automatically loads weights
# Set model config (confidence threshold) - we will filter results manually too
# model.conf = CONF_THRESH # (alternative to manual filtering)

# -----
# Prepare video I/O
# -----
cap = cv2.VideoCapture(VIDEO_PATH)
if not cap.isOpened():
    raise FileNotFoundError(f"Cannot open video file {VIDEO_PATH}")

fps = cap.get(cv2.CAP_PROP_FPS) or 25.0
width = int(cap.get(cv2.CAP_PROP_FRAME_WIDTH))
height = int(cap.get(cv2.CAP_PROP_FRAME_HEIGHT))
total_frames = int(cap.get(cv2.CAP_PROP_FRAME_COUNT))

fourcc = cv2.VideoWriter_fourcc(*'mp4v')
out_vid = cv2.VideoWriter(OUTPUT_VIDEO, fourcc, fps /
SAMPLE_EVERY_N_FRAMES, (width, height))

print(f"Video opened: {VIDEO_PATH} (frames={total_frames}, fps={fps},
size={width}x{height})")

# Load COCO names if possible (Ultralytics may have built-in names)
COCO_NAMES = model.names if hasattr(model, 'names') else None
if COCO_NAMES is None:
    COCO_NAMES = {'0': 'person'} # fallback; but ultralytics usually provides names

# Map desired vehicle class indices
vehicle_class_ids = [i for i, n in COCO_NAMES.items() if n in
VEHICLE_CLASS_NAMES]

# Prepare CSV
csv_file = open(CSV_OUTPUT, mode='w', newline='')
csv_writer = csv.writer(csv_file)
csv_writer.writerow(["frame_idx", "time_s", "car_count", "motorcycle_count",
"bus_count", "truck_count", "bicycle_count", "total_count", "density"])

# Process frames

```



```

frame_idx = 0
processed = 0
counts_over_time = []

pbar = tqdm(total=total_frames // SAMPLE_EVERY_N_FRAMES + 1,
desc="Processing frames")
while True:
    ret, frame = cap.read()
    if not ret:
        break
    frame_idx += 1
    if (frame_idx - 1) % SAMPLE_EVERY_N_FRAMES != 0:
        continue

    # Inference
    # Note: ultralytics model can accept numpy BGR images directly
    results = model.predict(source=frame, conf=CONF_THRESH, device=DEVICE,
imgsz=640, verbose=False)

    # results is a list; take the first
    res = results[0]
    boxes = getattr(res, 'boxes', None)
    car_count = motorcycle_count = bus_count = truck_count = bicycle_count = 0

    # Draw detections
    if boxes is not None and len(boxes) > 0:
        # boxes.boxes: xyxy, boxes.cls, boxes.conf in new versions. Use attributes robustly.
        # Get arrays safely
        xyxy = boxes.xyxy.cpu().numpy() if hasattr(boxes, 'xyxy') else np.array([])
        cls_ids = boxes.cls.cpu().numpy().astype(int) if hasattr(boxes, 'cls') else np.array([])
        confidences = boxes.conf.cpu().numpy() if hasattr(boxes, 'conf') else np.array([])

        for i, (b, cls_id, conf) in enumerate(zip(xyxy, cls_ids, confidences)):
            x1, y1, x2, y2 = b
            area = (x2 - x1) * (y2 - y1)
            if area < MIN_BOX_AREA: # ignore tiny boxes
                continue
            cls_name = COCO_NAMES.get(int(cls_id), str(cls_id))
            # Count vehicle classes
            if cls_name == 'car':
                car_count += 1
            elif cls_name == 'motorcycle':
                motorcycle_count += 1
            elif cls_name == 'bus':
                bus_count += 1

```

```

        elif cls_name == 'truck':
            truck_count += 1
        elif cls_name == 'bicycle':
            bicycle_count += 1
        # draw
        draw_overlay(frame, b, cls_name, float(conf))

    total_count = car_count + motorcycle_count + bus_count + truck_count +
bicycle_count
    density_label = classify_density(total_count)

    # Overlay counts and density on frame
    info_text = f"Frame: {frame_idx} Vehicles: {total_count} Density: {density_label}"
    cv2.putText(frame, info_text, (10, 25), cv2.FONT_HERSHEY_SIMPLEX, 0.7, (0,0,0),
4, cv2.LINE_AA)
    cv2.putText(frame, info_text, (10, 25), cv2.FONT_HERSHEY_SIMPLEX, 0.7,
(255,255,255), 1, cv2.LINE_AA)

    # Add colored density band
    if density_label == "LOW":
        band_color = (0, 255, 0)
    elif density_label == "MEDIUM":
        band_color = (0, 215, 255)
    else:
        band_color = (0, 0, 255)
    cv2.rectangle(frame, (0, height-40), (width, height), band_color, -1)
    cv2.putText(frame, f"Density: {density_label}", (10, height-12),
cv2.FONT_HERSHEY_SIMPLEX, 0.7, (255,255,255), 1, cv2.LINE_AA)

    # Write frame to output video
    out_vid.write(frame)

    # Record counts
    time_s = frame_idx / fps
    csv_writer.writerow([frame_idx, f"{time_s:.3f}", car_count, motorcycle_count,
bus_count, truck_count, bicycle_count, total_count, density_label])
    counts_over_time.append((frame_idx, time_s, total_count, density_label))

    processed += 1
    pbar.update(1)

pbar.close()
csv_file.close()
cap.release()
out_vid.release()

```

```

print(f"Processing complete. Processed frames: {processed}")
print(f"Annotated video saved to: {OUTPUT_VIDEO}")
print(f"Counts CSV saved to: {CSV_OUTPUT}")

# -----
# Plot: Vehicle count vs time
# -----
frames = [x[0] for x in counts_over_time]
times = [x[1] for x in counts_over_time]
totals = [x[2] for x in counts_over_time]
densities = [x[3] for x in counts_over_time]

plt.figure(figsize=(12,5))
plt.plot(times, totals, marker='o', linewidth=1, markersize=3)
plt.title("Vehicle count vs Time")
plt.xlabel("Time (s)")
plt.ylabel("Vehicle count (per frame)")
# Highlight density thresholds
low_thr = DENSITY_THRESHOLDS["low"]
med_thr = DENSITY_THRESHOLDS["medium"]
plt.axhline(low_thr, linestyle='--', label=f"Low threshold ({low_thr})")
plt.axhline(med_thr, linestyle='--', label=f"Medium threshold ({med_thr})")
plt.legend()
plt.grid(True)
plt.tight_layout()
plt.savefig("vehicle_count_timeseries.png", dpi=200)
print("Plot saved to vehicle_count_timeseries.png")
plt.show()

# =====
# New Cell
# =====

```